



Specifications for applying the  
**SkateMaster Coating System**  
For In-Line Hockey

CMT - 34

Revised: 7/04

**PRODUCT NAME:**

SkateMaster Coating  
System For In-Line Hockey

**MANUFACTURER:**

ThorWorks Industries, Inc.  
2520 S. Campbell St.  
Sandusky, OH 44870  
Phone: 800-326-1994  
Fax: 419-626-5477  
www.thorworks.com

*Additional Plant Locations:*  
SealMaster has a nationwide  
network of manufacturing and  
distribution facilities.

Phone 1-800-395-7325 or visit  
www.sealmaster.net to find the  
location near you.

**1. SCOPE:**

**1.1**

The following specifications pertain  
to the application of the  
SkateMaster Coating System for In-  
Line Hockey.

**2. SURFACE PREPARATION:**

**2.1**

New asphalt surfaces must cure 30  
days prior to application. The  
surface must be cleaned entirely  
of dust, dirt, debris, and all loose  
materials.

**2.2**

Fill all cracks with Acrylic Crack  
Patch, or other suitable crack filler.

**2.3**

Level depressions or "bird baths" (?  
inch or deeper) with SportMaster  
Acrylic Patch Binder or Acrylic  
Resurfacer patching mix.

**2.4**

Apply one coat of SportMaster  
Acrylic Resurfacer in accordance  
with manufacturer's mixing and  
application instructions.

*Important* - The sand used in the  
Acrylic Resurfacer should be a 70  
mesh or finer. Extremely porous  
asphalt may require a second coat  
of resurfacer.

**3. APPLICATION OF  
SKATEMASTER:**

**3.1**

Over properly prepared asphalt  
surface, apply two coats of  
SkateMaster coating in  
accordance with manufacturer's  
instructions.

**4. LINE MARKINGS:**

**4.1**

All line markings shall be laid out in  
accordance with The National In-  
Line Hockey Association guidelines.

**4.2**

Apply one or two coats of  
SportMaster Line Paint.